








Micro and multi-duct accessories

FGC 101 736

Product no. / QTY	Description	Layout
NTM 504 032 (25 pcs)	<p>Microducts end caps</p> <p>End caps have two major functions; They prevent dirt and moisture migrating into tubes and they lock the installed fiber to prevent it from moving in the tube. End caps should be used for all open ends in micro-duct installations.</p> <p>The end cap is made of rubber and provided with a slit to allow the fiber unit to pass through.</p>	
NTM 502 07 (100 pcs)	<p>Cleaning Sponge</p> <p>The cleaning sponge is used when testing or cleaning a micro-duct from dust or moisture. The sponge is simply blown through the micro-duct by the air pressure from the installation tool.</p>	
NTM 502 06 (100 pcs) NTM 502 06/1 (100 pcs)	<p>Blowing beads</p> <p>The beads can be an option to be put in the front end of the blown fiber unit. This is recommended for long installation distances with many duct connectors or sharp bends. NTM 502 06 is used for fiber units with 1 to 4 fibers. NTM 502 06/1 is used for fiber units with 8 fibers.</p>	

<p>MPB 306 01</p>	<p>Micro-duct Connectors Clip-in duct connectors are used to join two 5 mm diameter micro-ducts. The installation is simple and carried out in a few seconds.</p> <p>The connector is transparent to allow for visual inspection of a fiber unit passing through. To enable fiber blowing, the connector is designed to operate at 10 bars without leakage.</p>	
<p>MPB 306 02</p>	<p>Micro-duct gas seal connector The gas seal connector is used when there is a need to block moisture (avoid condensation) or gas to pass freely into different micro-duct sections. This could for example be necessary when changing from outdoor to indoor installations.</p> <p>The connector works in a similar way as the standard connector when joining micro-ducts but has a compressible rubber gasket that is sealed after the fiber has been installed.</p>	
<p>MPB 306 04</p>	<p>Bulkhead connector This micro-duct connector is designed to “snap in” to a 1.3 mm connector panel using 12.5 mm mounting holes.</p>	
<p>SXA 113 9137</p>	<p>Micro-duct end stop The end stop connector is used to block dirt, moisture and water penetration of typically installed but empty micro-ducts.</p>	
<p>SRS 106 17/01 (100 pcs) SRS 106 17/02 (100 pcs) SRS 106 17/03 (50 pcs) SRS 106 17/04 (20 pcs)</p>	<p>Multi-duct end caps The multi duct end caps are used for protecting the ducts from dust, insects or moisture during storage and installation.</p> <p>10-16 mm for 1, 2 and 4 multi-ducts 15-21 mm for 7 multi-duct 21-29 mm for 12 and 19 multi-ducts 29-38 mm for 24 multi-duct</p>	